

INSTRUCTION SHEET FOR 1965 CORVAIR  
FRONT MOUNT ANTENNA

1. Align and tape template on R.H. front fender. Drill holes as instructed on template.
2. Attach cable assembly to antenna body and tighten securely with gas pliers.
3. Unscrew mounting nut on antenna body. All parts will be loose.
4. Pass the antenna cable, base and rocker through the fender hole. Pull mast up vertically until rocker fits against underside of fender. Replace all parts and tighten mounting nut securely.
5. Remove grille panel and route cable assembly through existing hole in shroud side panel.
6. Break membrane in wiper harness grommet and route cable assembly through grommet and follow wiper motor harness into vehicle.
7. Connect cable assembly into radio receiver. Extend antenna mast completely and adjust trimmer according to receiver manufacturer's instructions.



